



Tuner Pioneer TX1070



Indicates the transistor section of an inherent resistor transistor.
 Indicates a transistor that does not have an inherent resistor.

Tuner Pioneer TX1070



1. RESISTORS.
Indicated in R, 1/4W, 1/8W, 5% tolerance unless otherwise noted K, K, M, M, (F), 1%, (G), 2%, (K), 10%, (M), 20% tolerance

2. CAPACITORS.
Indicated in capacity (μF)/voltage (V) unless otherwise noted p, pF. Indication without voltage is 50V except electrolytic capacitor.

3. VOLTAGE CURRENT.
DC voltage (V) at no input signal
mV : Signal voltage at FM 400Hz+75kHz DEV.

4. OTHERS:
Signal route.
Adjusting point.

The Δ mark found on same component parts indicates the importance of the safety factor of the part. There fore, when replacing, be sure to use parts of identical designation.